

DAMPER KIT DISTRIBUTION BOX

Installation instructions

Règles d'installation de base


Installatieprincipes


Installationsgrundlagen

Istruzioni di base




Build smart.








8




16




24




1




2




3





ENERGY



VENTILATION



BUILDING

Nederland • ☎ +31 313 480-300 • @ productadvieslijn@ubbink.nl


France • ☎ +33 (0)2 51 13 46 46 • @ ubbink@ubbink.fr

Belgium • ☎ +32 9 237 11 00 • @ info.bouw@ubbink.be

United Kingdom • ☎ +44 1604 433-000 • @ info@ubbink.co.uk

Deutschland • ☎ +49 2301 91011-0 • @ info@ubbink.de

Italia • ☎ +39 045 602 0433 • @ info@ubbink.it



Ubbink International

@ info@ubbink.com • 🌐 www.ubbink.com

Copyright © 2024 Ubbink | Content is subject to change without notice; no liability for errors and misprints. Availability and configurations may differ per country | UB-2024-08-V01

100000072746